

## HVLP Turbine Selector Guide

Coating to be sprayed:	T-55Q	T-75Q	T-90Q
Inks, thin stains, automotive base-clear etc. (Use nozzle 1.0 - 1.5 mm).	■	■	■
Lacquers, enamels, thin waterborne products, primers, aircraft paints etc. (Use nozzle 1.3 - 1.8 mm)	■	■	■
Latex, oils, aircraft dopes, industrial paints and primers. (Use nozzle 1.8 - 2.0 mm)	□	■	■
Multi color, thicker latex and oil paints. (Use nozzle 2.0 - 2.8 mm)	X	□	■
<b>Legend:</b> ■ = most suitable □ = suitable X = not suitable			