


# A-800 HVLP AIR SPRAY GUN

#L018-001 1,3mm

#L018-002 1,7mm



A= L018-050 1,3mm nozzle kit

L018-051 1,7mm nozzle kit

Pos.	Parts nos.	Description	Qty.
1	L015-433	Air Adj.Screw	1
2	L015-434	Air Adj.Knob	1
3*	L015-435	O-ring 2.5x2.1	1
4	L015-436	Flat washer	2
5	L015-437	Air valve spring	1
6	L015-438	Air valve step	1
7	L015-439	Spring	1
8		Washer	1
9*	L015-440	Air valve	1
10	310239	O-ring 8.5x1.2	1
11	L015-441	Seat	1
12*	L015-442	Foam washer	1
13*	L015-443	Washer	1
14	L015-444	Nut	1
17	L004-533	O-ring 11.2x1.6	1
19	L015-412	Packing nut	1
20*	L015-413	packing	1
21		Small washer	1
22	L015-414	Spring	1

Pos.	Parts nos.	Description	Qty.
23		Big washer	1
24	L015-445	Trigger pin I	1
25	L015-446	Trigger pin II	1
26	L015-447	Trigger	1
27	L015-425	Snap retainer	3
29	L015-475	Container	1
30	L015-684	Filter	1
31	L015-415	Fluid inlet joint	1
33	L015-422	Needle spring	1
34	L015-423	Nut	1
35	L015-424	Fluid Adj. Screw	1
36	L015-431	Bolt	1
37	L015-430	Pattern Adj. nut	1
38	L015-429	Pattern Adj. seat	1
39	L015-428	Pattern Adj. washer	1
40	L015-427	Pattern Adj. screw	1
41*	L015-426	O-ring 6x2	1
43	L015-432	Air inlet connector	1

\* L015-454 Seal kit (consisting of items marked \*)